

## **Fume Eliminator**

## Portable source capture directly on welding torch



The Fume Eliminator (also called a Smoke Eater) is designed to be carried to the working area. Connected to a welding torch or to an extraction nozzle, the FE unit extracts the fume directly at source. FE 840 has a manual start/stop function while the FE 841 has an automatic start/stop function, which starts the unit as soon as the welding begins.

- · Portable and easy to carry
- Low service costs
- Manual or automatic start/stop function
- User friendly

Product name	Fume Eliminator	
Noise level (dB(A))	73	
Filter efficiency (%)	99,7	
Installation	[Indoor]	
Material	Sheet metal	
Filter cleaning method	One way filter	
Working pressure (kPa)	22	
Max Airflow (m3/h)	150	
Hose Diameter (mm)	44	
Hose length (m)	2.5	
Frequency (Hz)	50	
No of phases	1	
Filter type	[cartridge]	
Number of filter elements	1	
Filter material	Cellulose	
Electric plug	UK	
Weight (kg)	16	
Power (kW)	1	
Note	Indicator for filter exchange	





## **Fume Eliminator**

Description	Power Voltage (V)	Model
FE 840 Manual start/stop	120	70840100
FE 840 Manual start/stop	230	70840442
FE 841 Automatic start/stop	230	70841010*
FE 841 Automatic start/stop	120	70841100*
FE 841 UK+Nozzle Kit Items included in the kit: 70841010: FE 841 Automatic start/stop 70854000: Funnel nozzle TM-200	230	70841400

<sup>\*</sup>Indicator for filter exchange



## **Fume Eliminator**

Accessory		Part No
	Filter (replacement) for Fume Eliminator	70324000
	Funnel nozzle TM-80	70851000
	Flange nozzle PM-300	70853000
	Funnel nozzle TM-200	70854000
2	Metal filter compl. for FE 840/841	70284001
0	Metal filter for FE 840/841	70282004
	Hose Superflex	70400026